

# SPOT GEN3

## FEATURES

### POWER INDICATOR

Flashes green when the device is switched on.

Flashes red when the battery is low. If this happens, please change the battery.

### POWER BUTTON

To switch the device on/off press and hold the power button and hold the power button until the power indicator flashes.

When the device is switched on all the lights will flash green to indicate the device has completed a successful self-test.

### ASSIST BUTTON

Can be used to activate an SOS Alarm.

### MANUAL POSITION/ END ACTIVITY

Depending on your configuration, this button can be used to log a Manual Position or End an Activity.

Press and hold until the indicator above starts flashing green.

### GPS INDICATOR

Flashes green when searching for a GPS signal.

Flashes red when unable to obtain a GPS signal.

### MESSAGE SENDING INDICATOR

Flashes green with GPS indicator when sending a message containing GPS information. It will continue to flash green until the message has been sent.

Flashes red when unable to send the message.

### SOS ALARM

To raise an SOS Alarm, remove the flap and press and hold the SOS button until the indicator next to it starts to flash green.

The GPS indicator will flash green to indicate it is looking for a GPS.

Once this has been found, both the GPS and Sending Message indicators will flash green to indicate the alarm has been sent to the ARC.



### AUTOMATIC POSITION

Press and hold the Automatic Position button until the indicator above starts flashing green.

The device will then attempt to send a position every 10 minutes for the next 24 Hours.

Press and hold to cancel the Automatic Position function.

### START ACTIVITY/ EXTEND ACTIVITY

Depending on your configuration, this button can be used to Start an Activity.

Press and hold until the indicator above starts flashing green.