




ANDROID APPLICATION USER GUIDE



Peoplesafe, Emerald House, East Street , Epsom, KT17 1HS

**Tel: +44 (0) 800 990 3562
Email: customer.support@peoplesafe.co.uk
www.peoplesafe.co.uk**

CONTENTS

	PAGE
WELCOME	4
Our Contact Details	
Disclaimer	
INSTALLATION	5
Set-up	
Verification	
ADDITIONAL SET-UP	7-8
Smart Button Set-up	
Connecting Smart Button to Application	
APPLICATION FEATURES	9-13
Manual Position	
Log Activity	
Text Activity	
Duress PIN	
Welfare PIN (add on)	
Check In/Out	
SOS Alarm	
Smart Button (add on)	
Fall Detection (add on)	
GENERAL SETTINGS	14-15
Bluetooth	
Voice Memo	
PIN Number	
Advanced Settings	
Title Selection Menu	
About	
Support	
Fall Detection	
Fall Detection Sensitivity	

WELCOME

Thank you for choosing the Peoplesafe Android application. This user guide provides instructions on the use of the software functions. Please read these instructions carefully and note that any changes made to the Peoplesafe application may change the functions of the software.

OUR CONTACT DETAILS

Emerald House, East Street, Epsom, Surrey KT17 1HS
Tel: 0800 990 3562 Email: customer.support@peoplesafe.co.uk
www.peoplesafe.co.uk

DISCLAIMER

It is important that you follow the instructions in this user guide carefully. Peoplesafe cannot be held liable for the non-performance of the Android application or the Alarm Receiving Centre (ARC) and any ensuing consequences, if you do not follow proper usage.

Deliberate false alarms or hoax activations are in breach of the Terms & Conditions and can result in termination of the service.

INSTALLATION

The following instructions guide you through the installation process. In order to complete the software installation, open the Android Play Store application on your handset and type into the search box 'Peoplesafe'. Once found, click on the download button to install the application onto your Smartphone handset.

SET-UP

Upon opening the application once installed, you will be presented with the 'Terms and Conditions' screen. Click the 'Agree' button to confirm your acceptance and to proceed. If you do not agree to the Terms & Conditions, the application will not function correctly and will close down.

You will also be presented with other permissions to accept. Please accept all permissions or else the application will not function correctly.

VERIFICATION

To complete the installation, a verification process is required to activate the application. To complete the verification process, enter your unique user ID and mobile phone number (in a 44 or 353 format) when prompted, and select 'Request Code'. The phone number field may already contain the handset's number; in which case, you do not need to enter it manually. This is dependent on the handset and network service provider.

Terms And Conditions

The agreement shall be considered to be in force when you have electronically accepted these terms and conditions or when you have started to use the service (whichever is earlier). If you do not wish to accept these terms and conditions you may not make use of the service.

Without limiting the validity or scope of the other terms and conditions that apply to the software (including the specific conditions that apply to the service for which the software will be used), the following shall apply. You may use the software for purposes and in the manner described in the online manual or in the terms and conditions. You may not disassemble, decompile, modify or use the software for other purposes or in other ways than are allowed under the applicable laws for Peoplesafe Software for Skyscan Limited ("PeopleSafe") or third parties. The license does not constitute, by implication or otherwise, any right to any trademark, name or commercial mark used in connection with the software or the service.

You acknowledge that there may be errors or defects in the service, as well as the information supplied through or in conjunction with the service. The service is provided "as is". You further acknowledge and understand that maps and other information provided by third parties on which the service is based are provided "as is" by such third parties, and that PeopleSafe accepts no responsibility for such errors or deficiencies. Notwithstanding the foregoing, PeopleSafe agrees to use reasonable efforts to as-

The screenshot shows a mobile application interface for Peoplesafe. At the top, there is a logo consisting of a stylized orange 'P' inside a square followed by the word 'PEOPLESAFE' in a sans-serif font. Below the logo, there are three input fields: 'Unique user ID:' with a placeholder box, 'User Token:' with a placeholder box, and 'Enter number:' with a placeholder box containing '+'. At the bottom of the screen is a large, light-colored rectangular button with the text 'Request Code' centered in it.


In order to find your individual user ID and user Token, please contact your account administrator. If you do not have an account administrator, please log on to the Peoplesafe Portal and create a user profile <https://portal.peoplesafe.co.uk> Upon completion, a unique user ID and user Token will be provided.

Once the user ID, user Token and phone number has been entered and you have requested your code, the application will require you to enter a verification code. You will receive this verification code via SMS text message, sent from Peoplesafe, to the phone number that was entered with the user ID. If the wrong phone number was entered at the previous stage, the verification code will not be sent to the correct handset. If a verification code is not received within 10 minutes, press the 'back' button to return to the user ID, user Token and phone number screen, where you can request another verification code.

Please ensure the phone number is in the correct format and is the correct number for the handset, when entered. Once you have received the SMS text message containing the verification code, enter it into the application's relevant field and press 'Done'. Please allow 5 minutes for software verification to take place.

After the verification process is complete, you will have access to the application and all of its services, such as setting activity timers and leaving activity information.

Installation is now complete.



ADDITIONAL SET-UP

SMART BUTTON SET-UP

If the additional Smart Button accessory has been purchased, the following instructions will explain how to connect it to the Peoplesafe application. If you have not purchased the accessory, please proceed to section 5.


CONNECTING SMART BUTTON WITH THE APPLICATION

To begin Smart Button set-up, the device must be switched on by pressing and holding the button for 10 seconds. Please note – should you need to switch the device off, press and hold the button for 30 seconds until three beeps are heard, followed by the LED flashing.

Navigate to the Bluetooth settings on your smartphone handset, ensuring Bluetooth is switched on. Select the Smart Button name from the list of devices available for pairing. This will be similar to the one in the screenshot to the right. Once the device has been selected, the handset will ask to be paired with the device. In order to pair correctly, a PIN number must be entered. (The default PIN code is '0000').



XT1072 is visible to nearby devices while Bluetooth settings is open.





Once the handset has successfully paired with the Smart Button, return to the handset's main menu and launch the 'Peoplesafe' application. When the main status screen appears, select the 'cog' menu button in the top right corner of the application to access the general features menu. Select the 'Bluetooth' option to connect to the new Smart Button.

Beneath the ‘Device’ heading by default it will show ‘none’, as you have not yet connected the Smart button accessory with the application itself. Click on the box that says ‘none’ to open a list of available Smart button devices that the phone is able to connect to. If there are lots of Bluetooth devices within range, you can use the V.ALRT Filter toggle so that the drop down only shows Bluetooth Buttons designed to be paired with the Peoplesafe app.

Select the device name that was originally paired with the phone. Once selected beneath the ‘Device’ heading, it will show which device the application is now connected to and its percentage battery life.

To disconnect from a Smart Button, press ‘Disconnect Device’ and then select ‘Yes’ when the pop up appears.



APPLICATION FEATURES



MANUAL POSITION

This option is used to manually send your GPS location via Data to Peoplesafe, where it will be accessible for the Alarm Receiving Centre and the Peoplesafe Portal. This information is stored against your profile and is accessible in the case of an alarm, or when a location report is requested.

To send a current location report, select the manual position button on the application's main screen. Whilst the handset tries to acquire an up-to-date location, the GPS status will turn yellow. The following notification will appear to indicate that the application is currently acquiring an updated position.


When a new position is acquired, the handset will vibrate and a pop up message “Position has been logged” will be displayed.

The Connections Status Box will also update the amount of positions sent and the last time the position was updated.



LOG ACTIVITY

This feature allows the user to log a timed activity. When the 'Log Activity' button is selected from the main screen, the application will automatically initiate a phone call to the Peoplesafe system.



Once connected, the user is prompted to enter their Activity PIN number. When entered successfully, the system will then request details of the user's activity, followed by the length of time they want to assign to the activity.

If the user wants to cancel or extend a current activity, they can do so by pressing the 'Log Activity' button again. After initiating the phone call and connecting to the Peoplesafe system, the user will be given the option either to extend or cancel their current activity.

TEXT ACTIVITY


This feature allows the user to log a timed activity via text rather than making a phone call.

When the text activity button is selected from the main screen, the user will be asked to enter their Activity PIN number. When entered successfully, the user will then be asked to input a timed duration in hours and minutes. Following this, the user will also be able to enter details of their activity, up to 256 characters, in the text box and then select text activity to complete the process. The amount of time remaining for the activity will be displayed on the text activity tile on the main application screen.



Text Activity
02:29:53

If the user wants to cancel, extend or update the description of a current activity, they can do so by pressing the text activity button again. The user will then be asked to enter their Activity PIN number. Once entered successfully, the user will get the option of selecting either the 'Extend Activity', 'End Activity' or 'Update Description' button providing that the description has been changed.



DURESS PIN


If a user needs to raise an alarm, but situation leaves them unable to use the methods mentioned in section 5.5, they can use the Duress PIN.

To use this feature, the user will need to press the Text Activity tile. Instead of entering their normal Activity PIN when prompted, the user will need to enter either 0000 or 9999, this will then show the message 'The activity has been cancelled' whilst discreetly raising an SOS Alarm to our Alarm Receiving Centre. The phone will then vibrate once the SOS Alarm message has been sent to the ARC.

WELFARE CHECK (ADD ON)

The welfare check is an add on that allows users to receive a check-up message if their activity is longer than 15 minutes.

Before setting an activity, users will be given the option to enable the Welfare Check feature as well as the timed interval they would like to receive the check-up message. Users will get a choice of receiving a check-up message at set intervals depending on the activity duration.



When the activity is set, the user will then receive the check-up message “Are you Okay?” at the timed interval selected. If the user selects ‘Yes’ they will be asked to enter their PIN again and the text activity will continue. The user can also select ‘Yes’ and then enter a Duress PIN instead if they need to discreetly raise an alarm. If the user selects ‘No’ or does not respond to the notification within 5 minutes, the activity will overrun and the system will raise an alarm.

CHECK IN/OUT

Using the Check In/Out features will send a position update to the Peoplesafe Portal, as well as an accompanying message. This feature can be used to let managers know when a worker has started and finished work.

When using the Check In/ Out feature, the user will also be asked if they wish to Set an Activity, Update the Description of an Activity or Cancel an Activity that is already active.

When the user selects Check In, but does not have an activity open, the user will be asked if they would like to set an activity as well.

If the user has already started an activity and then selects ‘Check In’ the user will be asked if they want to update the description of their activity.

If the user is in an activity and then selects ‘Check Out’ the user will then be notified that they are still in an activity and will be asked if they want to cancel that activity.

SOS ALARM

One of the ways a user can raise an alarm in the event of an emergency is by pressing and holding the 'SOS' alarm button on the main screen of the application. The button must be held for at least 3 seconds to raise an alarm. Alternatively, if the user has the application running in the background whilst the phone is locked, the user can press the 'Power Button' rapidly 4 times to raise an alarm.

If an alarm is raised successfully, the phone will vibrate and automatically initiate a phone call to our Alarm Receiving Centre. The application will also acquire an up-to-date GPS location – or most recently stored location, and send the information to Peoplesafe so the user can be located.

SMART BUTTON (ADD ON)

The Smart Button is an add on with two main functions – raising an alarm and updating the handset's current location. When the Smart Button is connected, and paired with the mobile handset, an alarm can be raised remotely, without the need to interact with the mobile handset. Holding the button down for 2 – 10 seconds and then releasing will raise an alarm. It is possible to manually update the handset's current location by pressing the button once.

FALL DETECTION (ADD ON)

The fall detection feature is an add on that enables an alarm to be raised without pressing a button. If fall detection is enabled, it will raise an alarm once it detects three factors – a fall from a height, a period of non-movement and a change in orientation. When all three factors have been detected, the smartphone will continuously vibrate to let the user know an alarm is about to be raised. In the event that an alarm is not necessary, simply shake the phone whilst it is vibrating to cancel the alarm; the phone will stop vibrating to indicate the alarm has been cancelled. If the phone registers all 3 criteria and the alarm does not get cancelled, it will trigger an alarm to the Alarm Receiving Centre.

GENERAL SETTINGS

Certain features in the application can be turned on and off via the settings menu. This makes the application customisable to each individual user and their activity. Depending on the user's tile selection, this menu will change to reflect those options not selected as a tile. This menu will also change depending on the features requested prior to setting up your account.

BLUETOOTH

Within this menu, Smart Button's features can be enabled and disabled by the user, such as LED alarm confirmation and sound/tone alarm confirmation. The Smart Button's battery percentage is also shown.

VOICE MEMO

This option allows the user to leave a voice message with useful information about their upcoming activity. However, this is purely for additional information and will not set a timer for the activity duration. The voice memo audio recording will be saved to the user's account and is accessible in the event of an emergency.

PIN NUMBER

When setting, extending or cancelling activities, you will be prompted to enter a unique activity PIN in order to proceed for security purposes. If you forget your unique activity pin, it can be viewed or refreshed anytime in the application's settings. Click on the settings 'cog' in the top right corner from the application's home screen and select 'PIN number'. The application will ask for a PIN to grant access, enter *#99*. Once access has been granted, it is possible to view your unique PIN number, alternatively you can request an update of your user PIN by pressing the 'Refresh' button.

ADVANCED SETTINGS

Further feature settings can be defined and set by Peoplesafe's technical staff.

TILE SELECTION MENU

Upon opening the application, you will notice 4 tiles surrounding the SOS Alarm button. These tiles are interchangeable via the settings menu. To change the tiles, simply click the settings in the top right-hand corner and select Tile Selection Menu in the settings list. From here you can customise which tiles you would like displayed on the application home screen.

ABOUT

Additional software information and contact/email information for Peoplesafe can be found here, if the user requires customer or technical support.

SUPPORT

Information about the application's features can be found here, to help the user utilise the application fully.

FALL DETECTION

If fall detection is requested prior to setting up your account, it will be available to activate within the tile selection menu at the point of installation. If the fall detection option has been requested once your account has been set up, our team will send the settings remotely and fall detection can then be activated. Similarly, it can also be deactivated by pressing the fall detection tile.

FALL DETECTION SENSITIVITY

As one of the parameters of detection is fall from a height, there are three different settings that can be changed for users of different heights, these can be accessed in the settings menu. These are Lower, Low, Medium and High. Low is recommended for taller users, Medium for average height users and High for shorter users; Lower is recommended for users whose fall detection alarm is triggering too easily on Low. Change these settings accordingly to ensure maximum accuracy when using fall detection.



PEOPLESAFE

PEOPLESAFE
EMERALD HOUSE
EAST STREET
EPSOM
KT17 1HS

TEL: +44 (0) 800 990 3562
EMAIL: CUSTOMER.SUPPORT@PEOPLESAFE.CO.UK
WWW.PEOPLESAFE.CO.UK